

# EZgate Quick startup guide

Rev. 4 – 17/04/11

## Hardware connection:

- 1.1 Open the bottom cover by removing the 4 screws.
- 1.2 Insert SIM card to SIM slot.
- 1.3 Connect GSM antenna to ANTENNA connector.
- 1.4 Connect Control pins to RELAY cable
- 1.5 Connect Power supply to POWER SUPPLY cable.
- 1.6 When power supply ON



Red Led will start blinking 1sec on, 1 sec off – searching for cellular network.

After around 30 second Red Led, blinking 3 second ON, 0.3 second OFF – lock on network.

When Green led light the EZgate ready to use.

## Add new phone number to the EZgate unit:

To insert register phone number to the EZgate

Please send SMS to the unit as follow:

Example: add new phone number 0541122333 with unit password 1234:

**P.1234A.0541122333**

EZgate will send back SMS to notify the new phone number add to the list of approve.

For more information how to setup the EZgate refer to SMS programming guide.

EZgate ready to use, you can call the EZgate and check the relay is working,

When calling the EZgate the Green Led will blink one time.

## Connection diagram:

